


Water flow

When the pump is powered on, the water is drawn from the skimmer's main drain and sent towards the filter.

Once filtered, the water is sent out towards the heat pump (if applicable), redirected to the chlorinator (if applicable), and finally sent back into the pool through the jets and the waterfall (should you have one).



Water thrust

- Pump
- Filter
- Heat pump (optional)
- Salt chlorinator (optional)
- Pool jet
- Water fall (optional)

Suction

- Main drain
- Skimmer
- Main drain valve
- Pipe leading to pump